

How to Mark the Position of Your Mailbox?

If you are unable to be at home when we install your mailbox we HIGHLY recommend marking the position for our installation team.

Time taken for installation – 30 to 60 minutes

Installation can be weather dependant.

How we install the mailbox

1. Arrive onsite and check we have the right home
2. Assess the home for the best location of the mailbox. OR assess the marked position for the mailbox. We are happy to contact you whilst we are there. To confirm your location and requirements. This needs to be arranged before the installation date.
3. Prepare the area for the mailbox.
4. Crane the mailbox into position.
5. Ensure that the mailbox is in the best position.
6. Check that the mailbox is level.
7. Finish the installation – backfill with sand.

IDEAS FOR MARKING YOUR LOCATION

- Use a spray can to mark the ground



Use a spray can to mark the ground

- Use bricks



Use Bricks

- Use cardboard cut to the approximate size of the mailbox. So the cardboard does not blow away place a stake in through the cardboard into the earth.



Use cardboard cut to the approximate size of the mailbox

- The location of your existing mailbox.



The location of your existing mailbox

- Use garden stake



Use a Garden Stake

- Dig the area out to the approximate dimensions and 100mm deep



Dig the area out to the approximate dimensions and 100mm deep

Installed Mailbox



Installed Mailbox

Dimensions required for mailboxes – The following are the base sizes:

AM WEDGE 500mm x 500mm

AM CLASSIC

AM CUBE

AM STONE

AM TIMBER

AM TRADITIONAL

AM TWIST – 600mm x 500mm

AM ELEGANT – 670mm x 500mm